

Fabricated Tee Type Strainers


Flow Rate Vs. Pressure Drop (Clean Screen)

For Liquids more viscous than water or where wire cloth liner is added, multiply the pressure drop in charts by:

Correction Factors				
Viscosity (SSU)	Perforated (1/8" Holes)	Perforated with Wire Cloth		
		40 Mesh	60 Mesh	80 Mesh
30	1.00	1.32	1.53	1.62
270	1.30	1.61	1.83	2.00
385	1.44	1.76	2.00	2.20
500	1.58	1.92	2.13	2.41
1,000	1.66	2.22	2.41	2.63
2,000	1.86	2.41	2.72	2.91



(Perforated basket 1/8" dia. holes on 3/16" centers)



Note: These charts are for theoretical calculations **ONLY**.

Please contact our office with your exact specifications and you will be provided with factory calculations.



Sure Flow
Equipment Inc.

Toll Free: 1-800-263-8251 Toll Free Fax: 1-800-876-1164
International: 1-905-335-1350 International Fax: 1-905-332-4993
Email: info@sureflowequipment.com www.sureflowequipment.com